QUANTIFI PHOTONICS®
A Teradyne Company

SWITCH

1000 SERIES

Optical switch

PXIE USER MANUAL



quantifiphotonics.com

Copyright © 2026 Quantifi Photonics Ltd All rights reserved.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, be it electronically, mechanically, or by any other means such as photocopying, recording or otherwise, without the prior written permission of Quantifi Photonics Ltd (Quantifi Photonics).

Information provided by Quantifi Photonics is believed to be accurate and reliable.
However, no responsibility is assumed by Quantifi Photonics for its use nor for any infringements of patents or other rights of third parties that may result from its use. No license is granted by implication or otherwise under any patent rights of Quantifi Photonics.

The information contained in this publication is subject to change without notice.

Trademarks

Quantifi Photonics' trademarks have been identified as such. However, the presence or absence of such identification does not affect the legal status of any trademark. All third party product and company names are trademarks™ or registered® trademarks of their respective holders. Neither Quantifi Photonics nor any software programs or other goods or services offered by Quantifi Photonics are affiliated with, endorsed by, or sponsored by the third parties listed below.

LabVIEW™ is a trademark of National Instruments. MATLAB® is a trademark of The MathWorks Inc. Python® is a trademark of the Python Software Foundation. Microsoft Edge®, and Microsoft Windows® are trademarks of the Microsoft Corporation. Google Chrome™ is a trademark of Google LLC.

Units of Measurement

Units of measurement in this publication conform to SI standards and practices.

CE mark related enquiries

EU Authorized Representative
Certification Company
Veluwezoom 42
1327 AH ALMERE
The Netherlands
+31 (0)36 202 40 37
info@certification-company.com

Manufacturer information

Quantifi Photonics Limited
12-14 Parkway Drive
Rosedale, Auckland 0632
New Zealand

User manual version: 5.08

Table of contents

1 What's in this user manual? 7
2 Conventions 8
3 Safety information 9
3.1 Optical laser radiation precautions 9
3.2 Electromagnetic compatibility 9
3.3 Electrostatic discharge precautions 10
4 Introducing the SWITCH Series 11
4.1 Hardware description 13
4.1.1 1x1, 1x2 & 1x4 Switch PXIe modules (1003 & 1008 examples) 13
4.1.2 Crossover Switch PXIe module 15
4.1.3 Duplex Switch PXIe module 16
4.1.4 1xN Switch PXIe modules (1106 example) 17
4.1.5 NxN grid optical switch (1201 example) 18
4.2 Port mappings 19
4.2.1 MTP-8 connectors 19
4.2.2 MTP-12 connectors 20
4.2.3 MTP-24 connectors 21
4.3 Status LEDs 22
4.3.1 1x1 & 1x4 SWITCH 22
4.3.2 1x2 SWITCH 22
4.3.3 Crossover SWITCH 22
4.3.4 Duplex SWITCH 23
4.3.5 1xN SWITCH 23
4.3.6 NxN SWITCH 23
4.4 Environmental conditions 24
5 Setting up hardware 25

5.1 Install the module in a PXIe chassis 26
5.2 Uninstall the module from a PXIe chassis 27
6 Installing software 28
6.1 Install the Cohesion Installer software package 29
6.2 Cohesion Manager 31
6.3 Cohesion Firmware Updater 32
7 CohesionUI - Overview 33
7.1 Access a module with CohesionUI 34
7.2 Display modules in a chassis 35
7.3 Select a module to work with 36
7.4 Manage CohesionUI settings 37
7.5 Synchronize and reinitialize CohesionUI 39
7.6 SCPI CohesionUI Command Console 41
7.7 View system information 44
7.7.1 PXIe Chassis 44
7.7.2 Module 44
8 Controlling your SWITCH with CohesionUI 45
8.1 SWITCH 1000 / 1100 / 1300 / 1400 Series 45
8.2 SWITCH 1200 Series / SWITCH 1309 module / SWITCH 1311 module (NxN grid optical switch) 46
9 Controlling your product with SCPI commands 49
9.1 Overview 49
9.2 Programming conventions 49
9.2.1 Index addressing of modules (slot, source) and units (channel) 50
9.3 Status and event registers 50
9.3.1 Standard Event Status Register 50
9.3.2 Standard Event Status Enable Register (Mask) 50
9.3.3 Status Byte Register 51

9.3.4 Service Request Enable Register (Mask) 51
9.3.5 Status and event registers diagram 52
9.4 PXIe Multi Chassis mode operation 53
9.4.1 NI-MAX application Multi Chassis mode 53
9.4.2 SCPI Multi Chassis commands 54
9.5 Command summary 56
9.5.1 Common commands 56
9.5.2 System commands 56
9.5.3 Slot commands 56
9.5.4 Configuration commands 57
9.6 Command descriptions 58
9.6.1 Common commands 58
9.6.2 System commands 59
9.6.3 Slot commands 60
9.6.4 Configuration Commands 61
9.7 Programming example: Control of the SWITCH with SCPI 64
10 Programming applications 65
10.1 Setting up NI-MAX application 66
10.2 Setting up NI-VISA application 67
10.3 Python® code example 68
10.4 MATLAB® code example 69
11 Working with optical fibers 70
12 System requirements 72
13 Maintenance 73
13.1 Annual calibration schedule 73
14 Technical Support 74
14.1 Contacting the Technical Support Group 74

14.2 Transportation 74
15 Warranty Information **75**
15.1 General information 75
15.2 Liability 75
15.3 Exclusions 75
15.4 Certification 76
15.5 Service and repairs 76

1 What's in this user manual?

You can find the following information in this document:

Before you begin	Conventions Safety information Working with optical fibers System requirements
Getting started	Introducing the SWITCH Series Setting up hardware Installing software
Working with your device	**CohesionUI GUI:** CohesionUI - Overview Controlling your SWITCH with CohesionUI **SCPI commands:** Controlling your product with SCPI commands Programming applications
Maintenance	Cohesion Manager Cohesion Firmware Updater

2 Conventions

Please make yourself familiar with these conventions; we use them throughout this user manual:

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in **death or serious injury**.

Do not proceed unless the required conditions are met and understood.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in **minor or moderate injury** or **component damage**.

Do not proceed unless the required conditions are met and understood.

NOTE

Indicates relevant information that requires your attention.

3 Safety information

Carefully read all safety information before using your Quantifi Photonics product.

3.1 Optical laser radiation precautions

WARNING

To protect yourself from harm caused by optical radiation:

- Do not install or terminate fibers while the light source is active.
- Turn the Quantifi Photonics product OFF before inspecting the end face(s) of the product, or any optical patch cords connected to it.
- Never look directly into a live fiber; ensure that your eyes are protected at all times.
- Equip all unused ports with protective caps or blanking covers.

CAUTION

The use of controls, adjustments, and procedures other than those specified in this document may result in exposure to hazardous situations involving optical radiation.

3.2 Electromagnetic compatibility

CAUTION

For electromagnetic compatibility, this product is a Class A product. It is intended for use in an industrial environment. There may be potential difficulties in ensuring electromagnetic compatibility in other environments, due to conducted as well as radiated disturbances.



This symbol on the unit refers to documentation provided with the product for related safety information. Ensure that the required conditions are met and understood before using the product.

3.3 Electrostatic discharge precautions

CAUTION

The product is sensitive to electrostatic discharge (ESD). To ensure that you do not cause ESD damage to the product:

- Always follow proper grounding and ESD management practices.
- Store the unused product in the original protective electrostatic packaging that it was shipped in.
- Use a wrist strap and grounding table mat when unpacking or handling the product.



4 Introducing the SWITCH Series

The SWITCH Series is an efficient solution for test procedure automation designed to be used on the National Instruments PXIe platform. The MEMS based optical switch ensures repeatable and low-loss switching to various test set-ups while taking advantage of the flexible connectivity and high channel density form-factor.

NOTE

All Crossover and Duplex Switch modules DO NOT HAVE A PARK STATE. When plugging optical fibres into the ports or inspecting fibres, ensure that the optical source is OFF to prevent user injury.



Programming interfaces


Through its programming interfaces you can take advantage of the SCPI-compliant command language and choose from programming tools such as LabView, C++, Python, or any of the other popular programming languages used to control automatic test equipment (ATE).

CohesionUI™


Quantifi Photonics' web-based graphical user interface CohesionUI is hosted on Microsoft Windows® and enables you to control your device from any supported web browser.

4.1 Hardware description

4.1.1 1x1, 1x2 & 1x4 Switch PXIe modules (1003 & 1008 examples)




1	Fastening screw	5	PXIe headers
2	Routing indicator LED	6	PXIe module / optical connector information
3	Common optical port	7	Fastening clip
4	Fastening screw		




1	Fastening screw	6a	Channel 4 common optical port
2	Routing indicator LED	6b	Channel 4 routing optical ports
3a	Channel 1 common optical port	7	PXIe module / optical connector information
3b	Channel 1 routing optical ports	8	Fastening clip
4a	Channel 2 common optical port	9	Switch PXIe module information
4b	Channel 2 routing optical ports	10	PXIe headers
5a	Channel 3 common optical port		
5b	Channel 3 routing optical ports		

4.1.2 Crossover Switch PXIe module




1	Fastening screw	5	PXIe module / optical connector information
2	Routing indicator LED	6	Fastening clip
3	A & B optical ports	7	PXIe headers
4	1 & 2 optical ports		

4.1.3 Duplex Switch PXIe module




1	Fastening screw	5a	A input / output optical port 2
2	Routing indicator LED	5b	B input / output optical port 2
3a	A common optical port	6	PXIe module / optical connector informationt
3b	B common optical port	7	Fastening clip
4a	A input / output optical port 1	8	PXIe headers
4b	B input / output optical port 1	9	Switch PXIe module information

4.1.4 1xN Switch PXIe modules (1106 example)



1	Fastening screw	5	PXIe module / optical connector information
2	Error status LED	6	Fastening clip
3	Common optical port	7	Switch PXIe module information
4	Routing optical ports	8	PXIe headers

4.1.5 NxN grid optical switch (1201 example)




1	Fastening screw	5	Fastening clip
2	Routing indicator LED	6	Module information
3	Breakout A optical ports	7	PXIe headers
4	Breakout B optical ports		

4.2 Port mappings


4.2.1 MTP-8 connectors

MTP-8 connectors on SWITCH PXIE modules are mapped as follows:




4.2.2 MTP-12 connectors

MTP-12 connectors on SWITCH PXIE modules are mapped as follows:



4.2.3 MTP-24 connectors

MTP-24 connectors on SWITCH PXIE modules are mapped as follows:



4.3 Status LEDs

The Status LEDs denote the operation state of the SWITCH products. The definition of LED states varies between switch models as shown below.

4.3.1 1x1 & 1x4 SWITCH

LED	Meaning
OFF	The SWITCH is powered OFF, or The SWITCH is in the PARK state (State 0).
flashing YELLOW	Indicates initialization on startup.
solid RED	Indicates a SWITCH error. Most often this means an invalid route position.
solid GREEN	Indicates which state the SWITCH is routed to.

4.3.2 1x2 SWITCH

LED	Meaning
OFF	The SWITCH is powered OFF
solid GREEN	Indicates successful initialization and communication.
solid RED	Indicates a SWITCH error. Most likely an initialization error at startup.

4.3.3 Crossover SWITCH

The SWITCH xx04 is a 2x2 crossover switch. This means that it has only 2 valid states: **Transmit (T)** and **Cross (C)**.

LED	Meaning
OFF	The SWITCH is powered OFF
solid GREEN	Indicates which state the SWITCH is in (default is **T**).
solid RED	Indicates there was an error in switching states. Only 1 LED will light up.

4.3.4 Duplex SWITCH

The SWITCH xx05 is a duplex switch. This means that it has only 2 valid states: **1** and **2**.

LED	Meaning
OFF	The SWITCH is powered OFF
solid GREEN	Indicates which state the SWITCH is in (default is **1**).
flashing RED	Indicates there was an error in switching states. Only 1 LED will light up.

4.3.5 1xN SWITCH

LED	Meaning
OFF	The SWITCH is powered OFF
flashing YELLOW	Indicates initialization on startup.
solid GREEN	Indicates successful initialization and communication.
solid RED	Indicates a SWITCH error. Most likely an initialization error at startup.

4.3.6 NxN SWITCH

LED	Meaning
OFF	The SWITCH is powered OFF
flashing YELLOW	Indicates initialization on startup.
solid GREEN	Indicates successful initialization and communication.
solid RED	Indicates a SWITCH error. Most likely an initialization error at startup.

4.4 Environmental conditions

Range of environmental conditions:

Indoor or outdoor use	Indoor only
Altitude	Max. 2000m
Operating temperature range	5°C to 45°C | 41°F to 113°F
Storage temperature range	-40°C to 70°C | -40°F to 158°F
Relative humidity range	20% to 80%
Supply voltage	12VDC, 2A & 3.3VDC, 3A

5 Setting up hardware

Quantifi Photonicsmodules are designed for easy installation in a PXIe-compatible chassis.

Make sure to follow these instructions when installing or removing a Quantifi Photonics module from a PXIe chassis.

Ensure that the chassis being used supports PXIe (or contains PXI-hybrid compatible slots). If you are unsure if your chassis is compatible with your Quantifi Photonics product, please contact Quantifi Photonics Customer Support.

CAUTION

The product is sensitive to electrostatic discharge (ESD). To prevent damage from ESD:

- Do not remove the product from the antistatic packaging until required to do so.
- Wear a grounded wrist strap at all times when handling the product.

CAUTION

Skin contact may leave corrosive residue and damage a connector:

- Always clean optical end faces before mating.

NOTE

Please check for the fiber end-face type of the optical ports, such as PC or APC, and only use the same type optical connector to avoid damaging the end-face.

For advice on connector and fiber care, please refer to Working with optical fibers.


5.1 Install the module in a PXIe chassis

WARNING


When attempting to install or remove a module or any component of the PXIe chassis:

- Power the chassis OFF.
- Follow these installation instructions.
- After powering the PXIe chassis ON, please wait at least 2 minutes before attempting to communicate with the module. This gives the chassis time to boot and initialize the communication server.


1 Power the chassis OFF.




2 Remove the module from the anti-static bag. Retain the bag.




3 Align the module with the slot guide rails.




4 Push module into slot until you feel resistance from the backplane connection.



5 Engage the fastening clip. Secure all fastening screws.



6 Power the chassis ON.




5.2 Uninstall the module from a PXIe chassis

WARNING


When attempting to install or remove a module or any component of the PXIe chassis:

- Power the chassis OFF.
- Follow these installation instructions.

1 Power the chassis OFF.




2 Unsecure the fastening screws and fastening clip.




3 Pull out the module.


Use the fastening clip to pull. Do NOT pull on the connectors.



4 Store the module in its antistatic bag.



5 Power ON the chassis.



6 Installing software

The Cohesion Installer software package enables communication between the PXIe controller and Quantifi Photonics modules installed in a chassis.

The Cohesion Installer contains all required drivers and software:

CohesionDriver	Driver Service for Quantifi Photonics PXIe modules
CohesionSCPI	VXI11 compliant server for remote SCPI communication
CohesionUI	Web-based Graphical User Interface
Cohesion Manager	Single-window utility application that shows the status of all Cohesion Software Services running on the system.
Cohesion Firmware Updater	Single-window utility application that shows the current firmware status of all Quantifi Photonics PXIe modules installed in the chassis.

6.1 Install the Cohesion Installer software package


Install Cohesion Installer on:


- the PXIe controller of the PXIe Chassis in which the Quantifi Photonics module(s) will be installed, or
- the controller PC (multi-chassis MXI setup)

▶ To install Cohesion Installer:


1. We recommended that you save your work and close open programs before installing Cohesion Installer.
2. Locate and run **CohesionInstaller-<version_number>.exe** from the provided USB media device (or download it from the Quantifi Photonics website) and follow the on-screen installation prompts.
3. Select the Installation Type: **CohesionUI with Apache** (this is the default setting)
4. Select the Chassis Mode: **Single Chassis Mode** (this is the default setting). If unsure, select this default setting.


   To operate in Multiple Chassis Mode, additional hardware modules are required. As you can change the Chassis Mode later, we recommend to select **Single Mode** unless all other configuration requirements have been met.





5. At the end of the installation, we recommend you select the **Reboot now** option, and click **Finish** to complete the installation process.
6. A Windows Security Alert may prompt the user for network access. We recommend that **both options are ticked**, to allow any network configuration.





7. On startup after rebooting the system a User Account Control prompt might be displayed.
   Click **Yes** to allow running of the **Cohesion Firmware Updater Utility** and proceed with the application.


6.2 Cohesion Manager

Cohesion Manager is a single-window utitlity application that shows the status of all Cohesion Software Services running on the system.

By default, these Cohesion Software Services will start automatically on startup of Windows and need to be running to facilitate proper communication with the Quantifi Photonics PXIe modules.

CohesionDriver	required	manages installed Quantifi Photonics modules
CohesionSCPI	required	VXI11 compliant SCPI interface for TCP communication with the installed Quantifi Photonics modules
CohesionUI	optional	web service providing a graphical interface for simplified operation of installed Quantifi Photonics modules

- To open Cohesion Manager:
  - Search for Cohesion Manager in the Windows Start Menu.
- From Cohesion Manager you can:
  1. Start or stop the CohesionDriver service, CohesionSCPI service, or CohesionUI service independently.
  2. View all installed Quantifi Photonics system utilities.
  3. In this example you can open the Cohesion Firmware Updater application.



- If you can't detect or communicate with modules:
  - Open Cohesion Manager.
  - Check the status of software services, and start a service if required.

6.3 Cohesion Firmware Updater

Cohesion Firmware Updater launches automatically when you install a new version of Cohesion Installer on the system and reboot. Or, you can open it via the Cohesion Manager application.


It is a single-window summary application that enables you to:

- view the current firmware status of all Quantifi Photonics PXIe modules installed in the chassis.
- update firmware to a new version if available.

> We recommended that you update firmware if a new version is available.

▶ To upgrade firmware:

1. Open **Cohesion Manager**, for example by searching for it in the Windows Start Menu.
2. In **Cohesion Manager**, click **Firmware Updater**.
3. Modules with out-of-date firmware are highlighted red.
4. Click **Automatic** to update automatically.
5. Progress will be displayed in **Update Status**.
6. Click **File** to update to a specific firmware package.




7 CohesionUI - Overview

CohesionUI is a web-based graphical interface that you can use to work with your Quantifi Photonics products.

> CohesionUI is part of the Cohesion Installer software package.

1. **HOME**: View all modules in the chassis
2. **MODULES**: Access a module
3. **SETTINGS**: Change CohesionUI settings
4. **CONSOLE**: Communicate with modules using SCPI commands
5. **INFO**: Display chassis information



7.1 Access a module with CohesionUI

You can access Quantifi Photonics modules via CohesionUI from the chassis controller, or from a controller PC.


To connect with a module, you need the IP address of the chassis the module is installed in.

- To obtain the IP address of the chassis:
  1. Open the **Command Prompt** window on the chassis controller.
  2. Run the `ipconfig` command.
  3. Note down the IPv4 address that is displayed.

- To connect with modules via CohesionUI:
  1. On the controller or controller PC, open CohesionUI, for example by double-clicking the desktop icon, or open a supported browser.
  2. Enter the IP address of the chassis as the URL.

     On the controller you can use `127.0.0.1` as the URL instead.


  3. CohesionUI will launch in the browser, listing all available Quantifi Photonics modules installed in the chassis.



7.2 Display modules in a chassis

The **HOME** page is the main landing page in CohesionUI; it displays all available Quantifi Photonics modules in the PXIe chassis.


1. Numbers indicate the slots the modules are installed in.
2. You can hide (default setting) or show empty slots in the PXIe chassis by toggling the **EMPTY SLOTS** button.
3. You can select a module to work with by clicking it.




7.3 Select a module to work with

To select a module:

1. Go to the **HOME** page.
2. Click the on the module.



3. Or, hover over the **MODULES** menu and select a module or channel from the list.



7.4 Manage CohesionUI settings

On the **SETTINGS** page you can configure CohesionUI settings and unit preferences.

> **NOTE**
>
> CohesionUI reverts to default settings when power-cycling the chassis.


▶ To view all settings and unit preferences and adjust as required:

1. Click **SETTINGS**.
2. Change settings or unit preferences as required, for example temperature units.
   Please note that the units displayed on this page are not always relevant for each product.
3. **Step size** refers to the amount by which a value is increased or decreased when clicking the **+** or **-** button.



To adjust unit preferences one at a time:

1. Hover over **SETTINGS**.
2. Select a unit from the dropdown, for example the power unit.



7.5 Synchronize and reinitialize CohesionUI

You can update CohesionUI with the latest information from your Quantifi Photonics modules by synchronizing or reinitializing.


Synchronizing	Updates **CohesionUI** with the latest information from the **CohesionSCPI service**
Reinitializing	Updates **CohesionUI and the CohesionSCPI service** with the latest information from the **CohesionDriver service**

This can be particularly useful when operating a multi-chassis MXI setup and enables you to:

- Re-discover modules that CohesionUI does not display as expected.
- Discover modules that have been installed after the initial startup.


▶ To **synchronize** CohesionUI across **all modules in all chassis**:

1. Click **SETTINGS**.
2. Click **SYNC**.
3. The page will be disabled while synchronizing.




- To **synchronize** CohesionUI across **all modules in a selected chassis** only:

  1. Click **HOME**.
  2. Click **SYNC** for a selected chassis.
  3. The page will be disabled while synchronizing.



- To **reinitialize** CohesionUI across **all modules in all chassis**:

  1. Click **SETTINGS**.
  2. Click **RE-INIT**.
  3. All modules will be disabled and temporarily disconnected while reinitializing.



7.6 SCPI CohesionUI Command Console


The CohesionUI SCPI Command Console enables you to communicate with Quantifi Photonics PXIE modules via SCPI commands. It enables you to test commands and verify their syntax.

For details on available SCPI commands, refer to the SCPI command section.

▶ To open the SCPI Command Console:


1. On the CohesionUI menu, click **CONSOLE**.
2. The console will appear in the bottom right corner of the screen.
3. You can move the console by clicking on the title bar and dragging it to any position on the screen. On closing and re-opening, the console will re-appear at its last position.

The console remains open when navigating between different modules. It floats on top of the UI so that you can observe the effect of SCPI commands on a module in real-time.



▶ To communicate with a module via the SCPI Command Console:

1. Enter a command.
2. Select action(s).
3. Review the action response in the output area.
4. (optional) Clear the output area.



You can choose from these SCPI command actions:

Action	Meaning	FAILED response
WRITE	Send the command to the instrument	The command is invalid. Please check the command and syntax.
READ	(after WRITE) Request the response from the instrument	Response buffer is empty.
QUERY	WRITE and READ	
*ESR?	Query the status event status register (ESR) – this will give you more details and specific information about command failures. For details on error codes, please refer to the programming guide in this manual.	
*CLS	Clear the response buffer and start fresh – useful when getting out of sync with WRITE and READ actions	

Example 1: Send instrument identification query `*idn?`

1. Enter the command: `*idn?`
2. Click **QUERY**.
3. The module returns the requested information.


Example 2: What happens when I send an incorrect command?


4. Enter an incorrect command, for example: ***ind?**
5. Click **QUERY**.
6. The module returns **FAILED**.


Example 3: Investigate a command failure:

7. Click `*ESR?` to query the event status register and request information about the command failure.
8. The instrument returns the error code, for example 32.

   For details on error codes, please refer to the *ESR? command in the programming guide.








7.7 View system information

7.7.1 PXIe Chassis

▶ To display chassis information:


1. Click **INFO**.
2. The information panel will display operation mode, manufacturer, model, and serial number of the chassis, and the version of CohesionUI and CohesionSCPI service running on the chassis.



7.7.2 Module

▶ To view module information when working with a module in CohesionUI:

1. Model number, serial number and firmware versions are displayed in the top right corner.




8 Controlling your SWITCH with CohesionUI

You can use Quantifi Photonics' graphical user interface CohesionUI to work with your module. For details on how to get started with CohesionUI, refer to CohesionUI - Overview.

8.1 SWITCH 1000 / 1100 / 1300 / 1400 Series


SWITCH-1309 module (5x5 grid optical switch) and SWITCH-1311 module (12x12 grid optical switch): Please refer to SWITCH 1200 Series / SWITCH 1309 module / SWITCH 1311 module (NxN grid optical switch).

The SWITCH is always in a **PARK** state by default. When in **PARK**, the SWITCH will act like an optical terminator.




To route the SWITCH to the desired port, click the port number (e.g. **PORT 2**). A grey circle will be displayed beside the current routed port.

The SWITCH can route the light very quickly, however there is a slight delay between re-routing the SWITCH and the UI updating the window.




8.2 SWITCH 1200 Series / SWITCH 1309 module / SWITCH 1311 module (NxN grid optical switch)


The SWITCH is always in a **PARK** state by default.



To route the SWITCH to the desired port, first click the intended **A port (INPUTS)** and then select the intended **B port (OUTPUTS)**:




Clicking **CONNECT** will set the routing state. Each routed port pair will be displayed in a green box in the **CONNECTED** list:




The SWITCH can route the light very quickly, however there is a slight delay between re-routing the SWITCH and CohesionUI updating the screen.

To disconnect a routed pair, click the red cross for the pair. To disconnect all routed pairs and set the routing for all **A ports (INPUTS)** to **PARK (0)**, you can click the **PARK ALL** button:



NOTE

When the **PARK ALL** button is clicked, a system popup will appear to confirm the action. By clicking this, all the connected port pairs will be disconnected and set to the default **PARK** state.



9 Controlling your product with SCPI commands

Remote communication with the CohesionSCPI service is achieved through the Standard Commands for Programmable Instruments (SCPI).

Support for VISA I/O API over TCP/IP is provided by the VXI-11 compliant CohesionSCPI service. With VISA communication drivers installed on the client, the implementation of VISA programming within environments such as MATLAB becomes available.

This section details the programming and measurement conventions to follow while executing the commands for the CohesionSCPI service.

NOTE

In NI-MAX a RIO interface will show up, however there are no communication methods available or implemented on this interface. Quantifi Photonics products are **ONLY** accessible through the **VISA TCPIP INSTR** interface provided by the CohesionSCPI service installed on the system.

9.1 Overview

You can operate your Quantifi Photonics module using SCPI commands.

For details on available SCPI commands, refer to:

- Command summary
- Command descriptions

9.2 Programming conventions

This section details the programming and measurement conventions to follow while executing the commands for the CohesionSCPI service.

Parameter	Default Unit	Alternative Units
Power	DBM	DBM
Frequency	HZ	THZ, GHZ, MHZ, KHZ
Frequency Fine	HZ	THZ, GHZ, MHZ, KHZ
Wavelength	M	NM, PM

Argument	Data Format
`<wsp>`	Specifies whitespace character (01_{16} – 09_{16}, $0B_{16}$ – 20_{16})
`<value>`	Is numerical data, an integer, a decimal, exponential (10e-9 or 5.8e6) or string
`[VALUE1 | VALUE2]`	A parameter choice. The '|' separates the unique parameters available, only one of the choices can be used. In the example, either the input parameter `[VALUE1]` or `[VALUE2]` can be used, but not both. Some commands may have more than two choices available. This parameter can be omitted where the command has a default defined in the command description.

9.2.1 Index addressing of modules (slot, source) and units (channel)

When executing commands, it is almost always necessary to provide the index of a specific module or an index of a specific installed unit.

For the commands that require index values:

Index	Description	Value
<c>	the chassis index in which the specific blade module is installed	integer, inclusive of 0
<n>	the slot (or source) index of the specific blade module	integer <1 to 18>
<m>	the channel index of a specific unit in the module	integer <1to 4>

Message queues

Information is exchanged in the form of messages. These messages are held in input and output queues.

The output queue stores responses to query commands. The CohesionSCPI service transmits any data in the output queue when a read request is received. Unless specified, all output response data is transmitted in ASCII format.

9.3 Status and event registers

9.3.1 Standard Event Status Register

The Standard Event Status Register (SESR) is modified by the Quantifi Photonics product with the results of the command operations.

Bit	Description
7 (MSB), 6	Not used
5	Is set when a Command Error event has been detected
4	Is set when a command Execution Error has been detected
3	Is set when a Device Dependent Error event has been detected
2	Is set when there a Query Error event has been detected
1	Not used
0 (LSB)	Is set when an Operation Complete event has been generated

9.3.2 Standard Event Status Enable Register (Mask)

The Standard Event Status Enable Register (SESR Mask) is used to build the Event Status Bit (ESB) within the Status Byte Register (STB). To ignore any of the events detected and set in the SESR, set the corresponding bit within the SESR Mask to 0. The STB can then be queried and the value of the ESB can be used to determine service request requirements based on the SESR Mask applied.

NOTE

The 0 (LSB) value within the SESR Mask is 0.

9.3.3 Status Byte Register

The Status Byte Register (STB) is built from all other status registers and masks. This register can be used in queries to determine if an event has been detected and where that event has been detected.


Bit	Description
7 (MSB)	Not used
6	The Master Summary Status (MSS) bit is set from the STB and SRE Mask
5	The Event Status Bit (ESB) is set from the SESR and the SESR Mask
4	Message Available (MAV) is set when there is data in the output queue
3, 2, 1, 0 (LSB)	Not used

9.3.4 Service Request Enable Register (Mask)

The Standard Request Enable Register (SRE Mask) is used to build the Master Summary Status Bit (MSS) within the Status Byte Register (STB). To ignore any of the events detected and set in the STB register itself, set the corresponding bit within the SRE Mask to 0. The STB can then be queried and the value of the MSS can be used to determine the type of service request required based on the SRE Mask applied.

Bit	Description
7 (MSB)	Not used
6	The Master Summary Status (MSS) bit is set from the STB and SRE Mask
5	The Event Status Bit (ESB) is set from the SESR and the SESR Mask
4	Message Available (MAV) is set when there is data in the output queue
3, 2, 1, 0 (LSB)	Not used

9.3.5 Status and event registers diagram



9.4 PXIe Multi Chassis mode operation

Multiple chassis can be connected to operate in **Multi Chassis Mode**.

To operate in Multi Chassis Mode, **CohesionSCPI service must be version 1.02.06 or later**.


9.4.1 NI-MAX application Multi Chassis mode

NOTE

The CohesionSCPI service does not manage the chassis numbers. These are controlled by the NI Platform Services (and through NI-MAX).

Even if the CohesionSCPI service is in Multi Chassis mode, if a chassis is connected but has no installed modules, it will not show up when `*OPT?` is run.

In the example shown below, there are two chassis connected via the PXIe-8384 to PXIe-8381 connection. Chassis #2 has the controller running CohesionSCPI service, and Chassis #3 is the 'extended' chassis.



9.4.2 SCPI Multi Chassis commands

NOTE

Changing the CohesionSCPI service Chassis Mode will rediscover all Chassis and installed modules.

Command	`:SYSTEM:CHASSIS?`
Syntax	`:SYSTEM:CHASSIS?<wsp>[LIST|MODE]`
Description	Query the Chassis Mode configuration
Parameters	No parameters
Response	**`List`**: Returns a comma separated list of valid chassis index numbers discovered by the CohesionSCPI service. These are chassis that have modules installed.
	`MODE`: Returns the current Chassis Mode the CohesionSCPI service is operating in (SINGLE or MULTI).
	`None`: Returns the number of chassis managed by the CohesionSCPI service. If this is greater than 1, then the system should be set to MULTI mode for correct operation.

Example	In Single chassis mode:
	`:SYSTEM:CHASSIS? -> 1`
	`:SYSTEM:CHASSIS? LIST -> 0`
	`:SYSTEM:CHASSIS? MODE -> SINGLE`
	
	In Multi chassis mode:
	`:SYSTEM:CHASSIS? -> 2`
	`:SYSTEM:CHASSIS? LIST -> 2,3`
	`:SYSTEM:CHASSIS? MODE -> MULTI`

Command	`:SYSTEM:CHASSIS`
Syntax	`:SYSTEM:CHASSIS<wsp>[SINGLE|MULTI]`
Description	Set the Chassis Mode configuration
Parameters	**`SINGLE`**: Set CohesionSCPI service to operate in SINGLE Chassis Mode
	`MULTI`: Set CohesionSCPI service to operate in MULTI Chassis Mode
Response	No response
Example	`:SYSTEM:CHASSIS SINGLE`

In Multi chassis mode, all commands listed in the command summary section will still work, but they must be prefixed with `:CHASSIS<c>`.

Common command example:

Single Chassis Mode	`:SLOT2:IDN?`
Multi Chassis Mode	`:CHASSIS1:SLOT2:IDN?`

Specific command example:

Single Chassis Mode	`:SOUR2:CHAN2:POW? MAX`
Multi Chassis Mode	`:CHASSIS1:SOUR2:CHAN2:POW? MAX`

9.5 Command summary

9.5.1 Common commands

Command	Description
`*CLS`	Clear session message queues >>
`*IDN?`	Query the CohesionSCPI service identification >>
`*OPC?`	Query the Operation Complete Status >>
`*OPT?`	Query the modules managed by the CohesionSCPI service >>
`*ESR?`	Query the Standard Event Status Register >>

9.5.2 System commands

Command	Description
`:SYSTEM`	
`:PRESet`	Restore module settings of all modules to power-on default values >>

9.5.3 Slot commands

Slot commands	Description
`:SLOT<n>`	
`:OPC?`	Query the Operation Complete Status of the module >>
`:OPTions?`	Query the modules managed by the CohesionSCPI service >>
`:IDN?`	Query the slot identification >>
`:PRESet`	Restore module settings to power-on default values >>

9.5.4 Configuration commands

Configuration commands	Description
:ROUTe<n>	
:ERROR?	Query the error status of the SWITCH >>
:CHANnel<m>	
:ERROR?	Query the error status of the specified channel of the SWITCH >>
:PORTS?	Query the number of ports on the SWITCH >>
:STATE?	Query the routing state of the SWITCH >>
:STATE	Set the routing state of the SWITCH >>

9.6 Command descriptions

9.6.1 Common commands

Command	***CLS**	Summary >>
Syntax	`*CLS`	
Description	Clear session message queues	
Parameters	N/A	
Response	N/A	
Example	`*CLS`	

Command	***IDN?**	Summary >>
Syntax	`*IDN?`	
Description	Query the CohesionSCPI service identification	
Parameters	N/A	
Response	Comma separated string with the <manufacturer>,<server name>,<chassis controller name>,<server version>	
Example	`*IDN? -> Quantifi Photonics, CohesionSCPIService,PXIE-8133,FW2.0.15`	

Command	***OPC?**	Summary >>
Syntax	`*OPC?`	
Description	Query the Operation Complete Status	
Parameters		
Response	**1**: all modules installed in the chassis are ready to execute commands	
	0: modules installed in the chassis still have commands to execute in the input queue	
	NOTE: Any commands sent to the module when `:MODUle:OPC?` is NOT equal `1`, may not execute or return an error.	
Example	`*OPC? -> 1`	

Command	***OPT?**	Summary >>
Syntax	`*OPT?`	
Description	Query the modules managed by the CohesionSCPI service	
Parameters	N/A	
Response	Comma separated string of the installed modules in the chassis	
Example	`*OPT? -> ,LASER-2001-1-FA-PXIE,SWITCH-1003-1-FC-PXIE,,VOA-1001-2-FA-PXIE,,,,O2E-1001-1-FC-PXIE,,,,,,,,`	

Command	***ESR?**		Summary >>
Syntax	`*ESR?`		
Description	Query the Standard Event Status Register		
Parameters	N/A		
Response	Unsigned integer 8 bit value for the register <0 to 255>, as a string.		
	Bit	Description	Decimal Value
	7 (MSB)	Not used	0
	6	Not used	0
	5	Command error	32
	4	Command Execution Error	16
	3	Device Dependent Error	8
	2	Not used	0
	1	Not used	0
	0 (LSB)	Operation Complete	1
Example	`*ESR? -> 8` `*ESR? -> 32`		

NOTE

It is recommended to use the `*ESR?` command query after every command that is sent to the device. The `*ESR?` query will be able to catch:

- **Device dependent Error** – the device is reporting an error in operation.
- **Execution Error** – SCPI was unable to execute the given command.
- **Command Error** – SCPI was unable to parse the given command, likely due to an incorrect command.

9.6.2 System commands

Command	**:SYSTEM:PRESet**	Summary >>
Syntax	`:SYSTEM:PRESet`	
Description	Restore module settings of all modules to power-on default values	
Parameters	N/A	
Response	N/A	
Example	`:SYSTEM:PRES`	

9.6.3 Slot commands

Command	**:SLOT<n>:OPC?**	Summary >>
Syntax	:SLOT<n>:OPC?	
Description	Query the Operation Complete Status of the module	
Parameters	N/A	
Response	**1**: the module is ready to accept a new command	
	0: the module is busy performing a previous operation	
	NOTE: Any commands sent to the module when :SLOT:OPC? is NOT 1, may not execute or return an error.	
Description	:SLOT1:OPC? -> 1	

Command	**:SLOT<n>:OPTions?**	Summary >>
Syntax	:SLOT<n>:OPTions?	
Description	Query the modules managed by the CohesionSCPI service	
Parameters	N/A	
Response	A comma separated array, or a single integer value based on the arguments given. If a module is not installed in a channel, it will not return any identification string.	
Example	:SLOT1:OPT? -> 1,1,,	

Command	**:SLOT<n>:IDN?**	Summary >>
Syntax	:SLOT<n>:IDN?	
Description	Query the slot identification	
Parameters	N/A	
Response	A comma-separated string containing "<manufacturer>,<part number>,<serial number>,<hardware version><firmware version>". Note that the hardware and firmware versions are not comma separated.	
Example	:SLOT1:IDN? -> Quantifi Photonics, POWER-1500-2-FC-PXIE, QP-192001, HW1.0FW1.02	

Command	**:SLOT<n>:PRESet**	Summary >>
Syntax	:SLOT<n>:PRESet	
Description	Restore module settings to power-on default values	
Parameters	N/A	
Response	N/A	
Example	:SLOT1:PRES	

9.6.4 Configuration Commands

Command	**:ROUTe<n>:ERROR?** Summary >>
Syntax	`:ROUTe<n>:ERROR?`
Description	Query the error status of the SWITCH
Parameters	N/A
Response	The response of an integer value representing a bitmask of switch errors.
	8: Switch D(4) reports an error
	4: Switch C(3) reports an error
	2: Switch B(2) reports an error
	1: Switch A(1) reports an error
	0: There are no reported errors
Example	`:ROUT1:ERROR? -> 1`

Command	**:ROUTe<n>:CHANnel<m>:ERROR?** Summary >>
Syntax	`:ROUTe<n>:CHANnel<m>:ERROR?`
Description	Query the error status of the specified channel of the SWITCH
Parameters	N/A
Response	**1**: SWITCH reporting an error
	0: No error on SWITCH
Example	`:ROUT1:CHAN1:ERROR? -> 0`

Command	**:ROUTe<n>:CHANnel<m>:PORTS?** Summary >>
Syntax	`:ROUTe<n>:CHANnel<m>:PORTS?`
Description	Query the number of ports on the SWITCH
Parameters	N/A
Response	A comma separated string denoting the port layout of the SWITCH 1200 Series as <value1>,<value2>, where the port layout of the SWITCH follows as value1 x value2. <value1> corresponds to the number of A ports, and <value2> corresponds to the number of B ports.
Example	`:ROUT1:CHAN1:PORTS? -> 8,8`

Command	**:ROUTe<n>:CHANnel<m>:STATE?**	Summary >>
Syntax	:ROUTe<n>:CHANnel<m>:STATE?<wsp>[SET|ACT|ACTUAL|ALL]	
Description	Query the routing state of the SWITCH ***SWITCH 1000/1100/1300/1400 Series***	
Parameters	**SET**: Returns the set routing state	
	ACT|ACTUAL: Returns the current position of the SWITCH routing state	
	ALL: Returns all the above values in a comma separated string	
Response		
Example	:ROUT8:CHAN1:STATE? -> 1	

Command	**:ROUTe<n>:CHANnel<m>:STATE?**	Summary >>
Syntax	:ROUTe<n>:CHANnel<m>:STATE?<wsp>[ALL]	
Description	Query the routing states for all the A ports of the SWITCH ***SWITCH 1200 Series / SWITCH-1309 / SWITCH-1311***	
Parameters	**ALL**: Returns the SET and ACT (actual) route state for each of the N A ports	
Response	If no parameter is provided, the response is a comma separated string of the SET route port for each A port as <SETA1>,<SETA2>,...<SETAN>. If the ALL parameter is provided, the response is a colon separated string representing the SET and ACT route values for each of the N A ports as <SETA1>,<ACTA1>:<SETA2>,<ACTA2>:...<SETAN>,<ACTAN>. Each A port's SET and ACT values are separated by a comma (,), and each port is separated by a colon (:).	
Example	:ROUT3:CHAN1:STATE? -> 2,4,6,8,1,3,0,7 :ROUTE3:CHAN1:STATE? ALL -> 2,2:4,4:6,6:8,8:1,1:3,3:0,0:7,7 Note: In this example the return indicates that port A1 has been set to B2 and is actually at B2, port A2 has been set to B4 and is actually at B4,...port A8 has been set to B7 and is actually at B7. Port A7 has been set to PARK and is actually in PARK.	

Command	**:ROUTe<n>:CHANnel<m>:STATE**	Summary >>
Syntax	:ROUTe<n>:CHANnel<m>:STATE<wsp><value>	
Description	Set the routing state of the SWITCH ***SWITCH 1000/1100/1300/1400 Series***	
Parameters	**<value>**: A valid number representing the routing state of the SWITCH	
Response	N/A	
Example	:ROUT1:CHAN1:STATE 2	

Command	**:ROUTe<n>:CHANnel<m>:STATE** Summary >>
Syntax	:ROUTe<n>:CHANnel<m>:STATE<wsp><value1>,<value2>…<valueN>
Description	Set the routing state of the N A ports of the SWITCH ***SWITCH 1200 Series / SWITCH-1309 / SWITCH-1311***
Parameters	The Switch 1200 PXIe Series are NxM grid switches, meaning that the intended route port for each of the N A ports must all be set together. Each of the N numbered A ports must be assigned a unique B port, numbered from 0 to M, where M is the number of B ports. **<value1>**: A valid port B number representing the routing port for Port A1. **<value2>**: A valid port B number representing the routing port for Port A2. **<valueN>**: A valid port B number representing the routing port for Port AN. A value of **0** denotes a PARK state.
Response	N/A
Example	:ROUT1:CHAN1:STATE 2,4,6,8,1,3,0,7 Note: In this example ports A1,A2,A3,A4,A5,A6,A7,A8 have been routed to ports B2,B4,B6,B8,B1,B3,PARK,B7.

9.7 Programming example: Control of the SWITCH with SCPI

The following is a simple example of how to control the SWITCH product using SCPI commands. See the previous section for specific details and extra parameters that the listed commands accept.

We recommend that you use the `*ESR?` query after every command that is sent to the device. This enables you to debug unreceived or incorrect commands sent to the product.

```
#Identifying the SWITCH
:*IDN?                                  #Query to confirm the correct module is setup
:*OPT?                                  #Query the available module configuration
:SLOT3:IDN?                             #Query the identification information for a specific slot module

#Setting the state of the SWITCH
:ROUTe3:CHANnel1:STATE 3                #Set the output route of the 1x4 Switch to port 3.
                                        #Default routing of a Switch is PARK (port 0).
:ROUTe3:CHANnel1:STATE 1                #Change the output route of the 1x4 Switch to port 1

#Querying the state of the SWITCH
:ROUTe3:CHANnel1:STATE?                 #Query the current route of the 1x4 Switch.
```

10 Programming applications

Remote communication with the CohesionSCPI service is achieved through the Standard Commands for Programmable Instruments (SCPI).

Support for VISA I/O API over TCP/IP is provided by the VXI-11 compliant CohesionSCPI service. With VISA communication drivers installed on the client, the implementation of VISA programming within environments such as MATLAB becomes available.

This section details the programming and measurement conventions to follow while executing the commands for the CohesionSCPI service.



NOTE

In NI-MAX a RIO interface will show up, however there are no communication methods available or implemented on this interface. Quantifi Photonics products are **ONLY** accessible through the **VISA TCPIP INSTR** interface provided by the CohesionSCPI service installed on the system.

10.1 Setting up NI-MAX application

To communicate with any Quantifi Photonics product, the chassis / benchtop product must first be setup as a TCP/IP instrument.

1. After installing NI-MAX, launch the application. In the left side panel of the window, click the **Devices and Interfaces** option. A drop down of available instruments detected will show up.
2. Click on **Network Devices**, then click **Add Network Devices** and select **VISA TCP/IP Resource**.

3. Select **Manual Entry of LAN Instrument**. Enter in the Hostname or IP Address.
   Note when operating locally, enter in the localhost IP address of **127.0.0.1**. Click **Finish** to end the setup process.






10.2 Setting up NI-VISA application


NI-VISA is used to communicate with the PXIe chassis or installed modules / instruments. The above steps must be completed before attempting to communicate using NI-VISA.

1. Launch NI-MAX. In the left-hand side menu, select an instrument from the **Network Devices** list.



2. On the right-hand side panel, select **Open VISA Test Panel**. A new window will popup. Click the **Input / Output** button from the window menu.

   Valid chassis and module commands can be entered in, and their returns queried



10.3 Python® code example

The following example shows how to communicate with the Quantifi Photonics product using Python code.

```
# You can get VXI11 from pip:
# pip install python-vxi11==0.9
import vxi11
from vxi11.vxi11 import Vxi11Exception
# replace this with the IP of your device
ip = "127.0.0.1"
try:
    print("connecting to " + ip + " ... ")
    instrument = vxi11.Instrument(ip)
    print("connected")
    print("checking IDN...")
    command = "*IDN?"
    data = instrument.ask(command)
    print("IDN: " + data)
    print("checking OPT...")
    command = "*OPT?"
    data = instrument.ask(command)
    print("OPT: " + data)
    # replace this with a valid command for your device (read # the programming guide section for examples)
    command = ""
    print("writing a specific command")
    instrument.write(command)
    print("checking ESR")
    command = "*ESR?"
    data = instrument.ask(command)
    print("*ESR?: " + data)
except Vxi11Exception as e:
    # pass
    print("ERROR" + str(e) + ", command: " + str(command))
```

10.4 MATLAB® code example

To communicate with the Quantifi Photonics product in MATLAB® the installation of a VISA IO driver is required. These drivers enable the creation of the Interface Object for instrument communication.

If developing locally on the PXIE Platform, then these will already be installed. However, if development is on a remotely connected system the VISA Libraries, e.g. National Instruments NI-VISA will have to be installed.

NOTE

MATLAB 2010x or later with the Instrument Control Toolbox is required to execute the code detailed in this section.

The following example shows how to communicate with a Quantifi Photonics product using MATLAB code.

```
% Find a VISA-TCPIP object. This is if the VISA object has already been
% created with tmtool or has been removed from the workspace without
% first being closed (cleanly disconnected).
PXIE_Chassis = instrfind('Type', 'visa-tcpip', ...
'RsrcName', 'TCPIP0::10.10.10.89::inst0::INSTR', 'Tag', '');
% Create the ‘agilent’ VISA-TCPIP object if it does not exist
% otherwise use the object that was found.
if isempty(PXIE_Chassis)
    PXIE_Chassis = visa('agilent', 'TCPIP0::10.10.10.89::inst0::INSTR');
else
    fclose(PXIE_Chassis);
    PXIE_Chassis = PXIE_Chassis (1);
end
% Open the connection to the VISA object.
fopen(PXIE_Chassis);
% Query the PXIE_Chassis.
response = query(PXIE_Chassis, '*IDN?');
disp('The *IDN query response:');
disp(response);
response = query(PXIE_Chassis, '*OPT?');
disp('The *OPT query response:');
disp(response);
% Replace this with a valid command for your device (read the programming
% guide section for examples)
command = ''
% Close the connection to the object.
```

11 Working with optical fibers

Quantifi Photonics products are equipped with high quality optical connectors in compliance with EIA-455-21A standards.

CAUTION

Keep connectors clean and in good condition to ensure maximum power and to avoid erroneous readings. Quantifi Photonics is not responsible for damage or errors caused by bad fiber cleaning or handling.

- Always inspect fiber end faces for cleanliness using a fiber inspection probe before inserting them into a port..
- If required, clean fibers and faces as detailed below.

NOTE

- To avoid damaging ferrules or fiber faces due to mismatched connectors, always check ports and connector type information before inserting a connector. All Quantifi Photonics units are labeled with connector type information.
- Failing to align and/or connect fiber-optic cables properly will result in significant signal loss and reflection.

▶ When connecting a fiber-optic cable to a port:

1. Visually inspect the fiber end face using a fiber inspection microscope.
2. If a **connector end face** is dirty:
    - Wipe the connector end face using a reel-type cleaner and inspect again.
    - For stubborn hard to clean connectors:
        - Use lint-free fiber-cleaning wipes soaked in a fiber optic cleaning solution.
        - Wipe the connector on the soaked part.
        - Dry the connector by wiping on the dry part of the wipe, or by using a reel-type cleaner.
    - Repeat the process until connector inspection shows a clean fiber face.
3. If a **bulkhead inner connector face** is dirty:
    - Use a pen-type dry cleaner, align the cleaning tip with the port and push the cleaner until you hear the characteristic click. Inspect again.
    - For stubborn hard to clean bulkhead connectors:
        - Use a stick-type cleaner dipped in a fiber optic cleaning solution.
        - Carefully align and insert the stick into the connector and gently rotate the stick for several seconds applying light pressure.
        - Use a pen-type cleaner to dry the connector.
    - Repeat the process until connector inspection shows a clean fiber face.
4. If the fiber end face is clean:
    - Carefully align the connector and port to prevent the fiber end from touching the outside of the port or other surfaces. If the connector features a key, mate it correctly into the corresponding notch of the port bulkhead.

- Push the connector in so that the fiber-optic cable is firmly in place with adequate contact. If your connector features a screw sleeve, tighten the connector to firmly maintain the fiber in place. Do not over-tighten, as this will dam-age the fiber and the port bulkhead.

12 System requirements

Quantifi Photonics PXIe modules

Supported browsers for working with CohesionUI	Google Chrome™ Microsoft Edge®
Chassis	PXIe-compatible chassis that • supports PXIe, or • contains PXI hybrid compatible slots
Recommended PXIe controller operating system	Microsoft Windows® 10 (64-bit)

Quantifi Photonics MATRIQ / EPIQ instruments

Supported browsers for working with CohesionUI	Google Chrome™ Microsoft Edge®
Recommended client computer operating system	Microsoft Windows® 10 (64-bit)

13 Maintenance

To help ensure long, trouble-free operation:

- Always inspect fiber-optic connectors before using them and clean them if necessary.
- Keep the unit free of dust.
- Store the unit at room temperature in a clean and dry area. Keep the unit out of direct sunlight.
- Avoid high humidity or significant temperature fluctuations.
- Avoid unnecessary shocks and vibrations.
- If any liquids are spilled on or into the unit, power off the chassis immediately. Remove the unit and allow to dry completely.



WARNING

The use of controls, adjustments, and procedures other than those specified herein may result in exposure to hazardous situations or impair the protection provided by this unit.

13.1 Annual calibration schedule

To ensure that the unit is performing within specification, we recommend it is re-calibrated every 12 months.

All Quantifi Photonics products are calibrated during manufacture, and each product is shipped to the customer with a Calibration Certificate. On this certificate, the calibration date, as well as the next calibration due date are mentioned.

We recommend your product is returned for re-calibration before the listed due date, to ensure continued performance of the product. For re-calibration service information, or to send in a product for re-calibration service, email support@quantifiphotonics.com.

If the Calibration Certificate has been misplaced, or the calibration due date is not known, email support@quantifiphotonics.com.

14 Technical Support

14.1 Contacting the Technical Support Group

To obtain after-sales service or technical support for this product, contact Quantifi Photonics:

support@quantifiphotonics.com

To accelerate the process, please provide information such as the name and the serial number of the product (see the product identification label), as well as a description of your problem.

14.2 Transportation

Maintain a temperature range within specifications when transporting the unit.

Transportation damage can occur from improper handling.

The following steps are recommended to minimize the possibility of damage:

- Pack the product in its original packing material when shipping. If the original packaging is unavailable, use appropriate foam packaging to provide shock absorption and avoid displacement of the product inside the shipping box. Please keep all input connectors covered with the supplied anti-static plastic covers during transport and avoid any shipping material making contact with the sensitive connectors of the product.
- Avoid high humidity or large temperature fluctuations.
- Keep the product out of direct sunlight.
- Avoid unnecessary shocks and vibrations.

15 Warranty Information

15.1 General information

Quantifi Photonics Ltd (Quantifi Photonics) warrants from the date of the original shipment (the Warranty Period) that this product will conform to specifications and will be free from defects in material and workmanship for the applicable Warranty Period. Quantifi Photonics also warrants that the equipment will meet applicable specifications under normal use.

NOTE

The warranty can become null and void if:

- The unit has been tampered with, repaired, or worked upon by unauthorized individuals or non-Quantifi Photonics personnel.
- The warranty sticker has been removed.
- The unit has been opened, other than as explained in this guide.
- The unit serial number has been altered, erased, or removed.
- The unit has been misused, neglected, or damaged by accident.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL QUANTIFI PHOTONICS BE LIABLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

For full warranty terms and conditions, please visit quantifiphotonics.com.

15.2 Liability

Quantifi Photonics shall not be liable for damages resulting from the use of the product, nor shall be responsible for any failure in the performance of other items to which the product is connected or the operation of any system of which the product may be a part.

Quantifi Photonics shall not be liable for damages resulting from improper usage, transportation or unauthorized modification of the product, its accompanying accessories and software.

The external power supply that has been supplied by Quantifi Photonics with the unit can only be used with that unit, do not use it with any other product.

15.3 Exclusions

Quantifi Photonics reserves the right to make changes in the design or construction of any of its products at any time without incurring obligation to make any changes whatsoever on units purchased. Accessories, including but not limited to fuses, pilot lamps, batteries and universal interfaces (EUI)

used with Quantifi Photonics products are not covered by this warranty.

This warranty excludes failure resulting from: Improper use or installation, normal wear and tear, accident, abuse, neglect, fire, water, lightning or other acts of nature, causes external to the product or other factors beyond the control of Quantifi Photonics.

15.4 Certification

Quantifi Photonics certifies that this equipment met its published specifications at the time of shipment from the factory.

15.5 Service and repairs

To send any equipment for service, repair or calibration please contact the Technical Support Group: support@quantifiphotonics.com.

QUANTIFI PHOTONICS®
A Teradyne Company

Test. Measure. Solve.™

Quantifi Photonics is transforming the world of photonics test and measurement. Our portfolio of optical and electrical test instruments is rapidly expanding to meet the needs of engineers and scientists around the globe. From enabling ground-breaking experiments to driving highly efficient production testing, you'll find us working with customers to solve complex problems with optimal solutions.

To find out more, get in touch with us today.

General Enquiries	sales@quantifiphotonics.com
Technical Support	support@quantifiphotonics.com
Phone	+64 9 478 4849
North America	+1-800-803-8872

quantifiphotonics.com